

# CYNCRA 2 GROUP INSTALLATION CHECKLIST





# **Quick Reference Specifications:**

**Dimensions**: 21"(H) 32"(W) 23"(D)

Weight: 173 lbs (full)

Electrical Requirements: Volts: 208-240/Amps: 30

<u>Plumbing Requirements</u>: Flow: 30GPH (minimum) Pressure: 35psi (minimum) Hardness: 3 GPG (maximum) Fitting: 3/8" MPT w/shut-off Drainage Requirements: Open gravity drain of 1.25" ID (min) within 4

feet of machine.

The following information will assist you in preparing your location for the installation of your equipment. Please make sure everything is prepared to these specifications *prior* to scheduling your installation. Once everything is complete, check the appropriate boxes and sign the bottom of the form.

# 21" 23" 23" WAITER FEITRATION COUNTER SPACE REQUIREMENTS: 32" 23" 23" 23" 23" 23"

### **WATER SUPPLY REQUIREMENTS:**

- \*Machine must be supplied with a minimum of 30 Gallons per hour @ 35 PSI.
- \*A 3/8" MPT is required for hook-up. A shut-off valve must be installed.
- \*If water hardness levels exceed 3 GPG (Grains per Gallon) a water softener MUST be installed. Exceeding these levels will void the manufacturer's warranty. (Check appropriate box below)
- I have tested the water hardness and it is 3 GPG or less (see above).
- I already have a suitable water softener and its output is 3 GPG or less (see above).
- ☐ I have tested the water hardness level and it is written above. Please supply me with the appropriate water softener at time of installation.

### **ELECTRICAL REQUIREMENTS:**

### 208-240V/30AMP/4000WATT

Dedicated 30 AMP Plug within 4 feet of installation location. PLEASE NOTE: The machine will not be supplied with a Cord Cap (Male plug).

## **DRAINAGE REQUIREMENTS:**

Access to open gravity drain no smaller than 1.25" ID (Inner Diameter). Drain MUST be within 4 feet of the machine for proper drainage.